

ONYX

TIME CHANGE

LIFT HANDSET

PRESS INTERCOM

PRESS PGM# (your display shows, "*DSS,EXT,6,9,8?*")

DIAL T (your display shows "*SET TIME HHMMSS.*")

ENTER THE HOUR (00 - 23; 0=12 MIDNIGHT; 12 = 12 NOON; 23= 11 PM)

ENTER THE MINUTES (00-59)

ENTER THE SECONDS (00-59)

HANG UP